RF Single Pole Switch with Neutral ZWL-MNS
RF Accessory Switch with Neutral ZWL-ANS

Installation Instructions

Important: Turn circuit breaker OFF or remove fuse(s) and test that power is off. Must be installed and used in accordance with electrical codes.

Caution: Use only copper wire with this device. Do not use with aluminum wire.



To install:

Connect wires per wiring diagram as follows:

- Remove pre-stripped insulation on device wires.
- Strip wires in box 1/2".
- Twist ends of stripped wires together as per schematic.
- Twist on wire connectors clockwise until secure.
- Connect green ground wire to bare wire, and mount to box with screws.

Z-Wave Device Network Installation

After completing successful installation LED on device will blink until added to the Z-Wave network. To add the device, refer to the instruction manual for your controller and press the ON/OFF switch one time. Once added, the blue LED will stop blinking.



FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1: This device may not cause harmful interference, and

2: This device must accept any interference received,including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION: Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.



Additional Information (Contact Info, Safety, Service & Support, Warranty)

Contacting RTI

For news about the latest updates, new product information, and new accessories, please visit our web site at: www.rticorp.com

For general information, you can contact RTI at: Remote Technologies Incorporated, 5775 12th Ave. E Suite 180, Shakopee, MN 55379, Tel. (952) 253-3100, Fax (952) 253-3131, info@rticorp.com

Safety Suggestions

Do not use unit near water, for example, near a sink, swimming pool, open window, in wet basement, etc.

Do not allow objects to fall or liquids to be spilled into the enclosure through openings.

Do not attempt any service beyond that described in the operating instructions. Refer all other service needs to qualified service personnel.

Service & Support

If you are encountering any problems or have a question about your RTI product, please contact RTI Technical Support for assistance. RTI provides technical support by telephone or e-mail. For the highest quality service, please have the following information ready:

Your Name • Company Name • Telephone Number • E-mail Address • Product model & serial no. (if applicable)

If you are having a problem with hardware, please note the equipment in your system, a description of the problem, and any troubleshooting you have already tried. *Please do not return products to RTI without return authorization.*

Limited Warranty

RTI warrants its products for a period of one (1) year (90 days only for included battery packs); or for a period of time compliant with local laws when applicable from the date of purchase from RTI or an authorized RTI distributor. This warranty may be enforced by the original purchaser and subsequent owners during the warranty period, so long as the original dated sales receipt or other proof of warranty coverage is presented when warranty service is required. Except as specified below, this warranty covers all defects in material and workmanship in this product.

The following are not covered by the warranty:

Damage resulting from:

1. Accident, misuse, abuse, or neglect.
2. Failure to follow instructions contained in this Guide.
3. Repair or attempted repair by anyone other than Remote Technologies Incorporated.
4. Failure to perform recommended periodic maintenance.
5. Causes other than product defects, including lack of skill, competence or experience of user.
6. Shipment of this product (claims must be made to the carrier).
7. Being altered or which the serial number has been defaced, modified or removed.